



# WIMS Offers A Winning Solution In Columbia, SC

## Hach System Improves Efficiency, Productivity For Wastewater Treatment Plant


Back in 2012, the City Of Columbia made the decision to update its OPS SQL software to Hach WIMS (water information management system). The old software was not only sitting idle, but was also out of date. The reasons for updating and implementing the software were many but can be summarized with the two primary goals: To collect the data into a central database that is easily accessible and to create a dashboard from which the rotating operations teams or management could quickly understand what was happening. Madeline Zimmerman, a senior staff Assistant with operating experience, and David Wiman, the operations supervisor, were the city champions for this endeavor.

After more than a year of coordinating Metro management and staff, Hach WIMS support staff, and city IT staff, WIMS began to take shape. Wiman and Zimmerman visited other entities that were currently utilizing WIMS and made notes about what they liked and didn't like. From these notes, Wiman designed various dashboards to meet their operational and management needs, and Zimmerman worked with Hach staff to get these created.

In mid-2015, Zimmerman left the city. Wiman, who had assumed the role of plant superintendent in January 2014, needed a new champion and tapped their laboratory manager, Sarah Hickman, for that role. Additionally, Chief Operator Adrian Martin began to work with

Hickman in order to update and add some flair to the dashboards.

Concurrently, Hickman, who had arrived at Metro in November 2014, had standardized the laboratory testing procedures so that the laboratory was now producing quality, reliable data. With dependable data in hand, the dashboards were finally rolled out to the operations teams for review in their shift-change meetings.



Previously, the plant personnel who were just arriving on the job would meet with those who were finishing their shift for a status report and to discuss any pressing issues. Yet, the meetings were often more obligatory than useful, largely because of the limited data available to share.

"Information from the previous shift was written in a notebook each day, but those were only single data points, which obviously made it difficult to get any sense of data trends," recalls Hickman.

"Someone would read off the information at shift change, but it was hard to pay attention. It was easy for the operators to get distracted by their phones since the data was not very useful as presented."

The shift changes were a symptom of a larger problem at the activated sludge wastewater treatment plant (WWTP) which treats on average 35 million gallons per day (MGD) of its rated capacity of 60 MGD. While considerable data and information was being generated on a regular basis throughout the plant, there was no integrated system to easily track, aggregate, and communicate that data in ways that could provide useful insights to monitor and improve operations. This proved problematic for a system that collects wastewater from approximately 63,000 approved connections along 1,000 miles of pipeline within the city limits, as well as into portions of two neighboring counties.

"Our situation with data was a bit chaotic," Hickman says. "There was data everywhere. We were using Excel, but Excel is Excel. We needed some type of solution to store and organize that data to help us make better and more timely operations' decisions." Wiman added, "The operators needed to understand how the treatment-process data was trending when they arrived at work. Understanding this helped them to learn the operational big-picture objectives and how decisions made in one treatment process could directly affect other treatment processes."

# Clean Water 2020 - Hach WIMS

Columbia's Clear Vision For Clean Water

Metro WWTP



Columbia WIMS Lab Dashboard

## WIMS Provides A Big Win

That answer came in the form of Hach WIMS, a real-time digital system that seamlessly integrates the collection, aggregation, and tracking of data, while also generating customized reports and presenting information and insights in easy-to-access customizable dashboards. There are more than 1,500 WIMS systems operating throughout North America. The solution has proven to be highly scalable and affordable, making it a viable option for remote groundwater installations on up to the largest municipalities in the nation.

In Columbia, the first sign that the WIMS system would prove to be a big win for the plant emerged in those shift-change meetings. Instead of someone simply rattling off numbers from a worksheet, the WIMS dashboard could be projected onto

a large Smart Board, presenting a dynamic view of a range of relevant and up-to-date data.

"The day we started using WIMS during shift change, everyone put down their phones and really got into the information on the screen," Hickman recalls. "They started asking questions and making suggestions. It was much more engaging. I thought that initial curiosity might wear off, but it hasn't. Those meetings are so valuable now, and everyone is focused on improving our performance because they can see how they can make an impact."

## Data Trends Offer Insights Into Operations

Particularly valuable has been the ability to clearly show data trends over varying time periods. By getting a holistic view of the data and trends, the team can more

easily identify where there might be a challenge or an issue that is emerging that needs to be addressed.

The WIMS system also allows for the creation of color-coded KPIs (key performance indicators). For instance, if a reading is within the normal range, it is signified by blue, while yellow provides a warning, and red indicates a problem. For certain parameters, the yellow and red readings automatically generate trigger reports that alert staff of a potential issue. The trend data also serves to keep employees up to speed on what is happening in the plant at any given time.

"We have rotating shifts, so people are off for two or three days at a time," Hickman says. "A lot can change over a couple of days at a wastewater treatment plant. Back when we were simply reciting data

off of paper, it was very difficult to process the information and act on it. Seeing the data in a trend makes it easier to quickly see what is going on." "Previously," Wiman recalled, "I would get calls at home from panicked operators asking what to do based on a single data point. I would ask them whether that data was trending up or down, and they didn't know."

### More Efficient Chemical Use

In Columbia, they are just beginning to identify the many benefits of the WIMS system beyond improving communication, collaboration, and bolstering employee engagement. WIMS is allowing for more efficient use of chemicals by clearly identifying trends and showing a more holistic view of overall plant operations through various data points that are presented on the dashboards.

For instance, previously the plant sometimes overused chlorine as a safeguard against levels dropping too low. Because real-time data was often lacking, more chemicals were used than needed to assure that the plant stayed in compliance. In early 2014, the city installed online instruments that were tied to their SCADA (supervisory control and data acquisition)

system, which provided reliable real-time data. Now the steady monitoring allows for more targeted use of chemicals, which improves efficiency and will lead to cost savings.

"We are feeding a lot less bleach and use a lot less sodium bisulfite for dechlorination," Hickman says. "Because the operators monitor the trends impacted by the chemical usage every day, chemical use in general has become much more efficient and effective."

### Customized Dashboards And On-Demand Reporting

Another key benefit has been the capability for customized dashboards offered by the WIMS system. That allows different users from throughout the plant to create dashboards that include only the information that is relevant for them. WIMS can also automatically generate and email on-demand customized reports that show data trends and selected information. For instance, solid-retention time reports are sent on a regular basis to plant engineers.

"Everyone can have their own dashboard and their own scheduled reports sent at specified intervals," Hickman says. "I want to see how the lab is performing for

quality control, while our director has a dashboard that provides high-level data such as daily flows for the last 12 months."

The facility aims to continue building on the capabilities offered by WIMS to improve productivity, performance, and operate the plant in the most cost-effective ways possible. "Currently our process data is displayed in process flow sequence," Wiman noted. "But we realize that certain process information is better understood if it is displayed with related data from other processes. For example, mixed liquor suspended solids (MLSS), return activated sludge (RAS) solids, and return rates, as well as secondary clarifier blanket depths, need to be trended together for the operator to fully understand how they work together to impact our solids retention time (SRT), which is the variable that ultimately drives our operational decision-making. So that is the next step in our improvement process."

"WIMS has proven to be a great tool for improving operations," Hickman says. "Now with a few clicks, we can get the information we need to make decisions and make sure everything is running smoothly." ■